

## 2 Assembly

## OMX300DI ORCA Connect 23L Dry Ice



Component		Quantity
А	Dry Ice	14 kg
В	Dry Ice Liner	1
С	ORCA Connect 23L Case	1
Di	Document Case	1
Dii	Logger Housing	1



## 2.1 Packing Instructions

- 2.1.1 Pack the ORCA Connect 23L Dry Ice system with the front of the case (C) closest to you. Make sure the chosen logger is added to the logger housing (Dii) and any documentation is placed in the document case (Di) before following the next steps.
- 2.1.2 Pour approximately 4 kg of dry ice (A) into the base of the Dry Ice Liner (B).
- 2.1.3 Place the payload on the dry ice in the centre of the system.
- 2.1.4 Pour the remaining 10 kg of dry ice (B) on top of the payload and close the dry ice liner box.
- 2.1.5 The lid can now be closed and secured by taping along the two areas marked with dotted lines and using security seals through the front locking tabs (C).
- 2.1.6 Your ORCA Connect 23L Dry Ice system is now ready to be shipped.